


Retractors



**RS-6500**

AGRICOLA
3x3 prongs
depth 4mm
spread 1"
length 1 1/2"

**RS-6502**

GOLDSTEIN
3x3 prongs
depth 5mm
spread 3/4"
length 1"



RS-6510 Shown

RS-6510

ALM
4x4 prongs
depth 3mm
spread 2 1/4"
length 2 3/4"

RS-6514

depth 13mm
spread 3"
length 4"



RS-6521 Shown

RS-6521


Cross Action Retractor
with ratchet
spread 1"
length 4"

RS-6524

angled
4x4 blunt prongs
straight
4x4 blunt prongs

**RS-6540**


BARRAQUER
wire blades
spread 12mm
blade width 10mm
length 1 3/4"



RS-6550 MURDOCK
non-magnetic, chrome
spread 38mm
blade width 15mm
length 2¹/₄"



RS-6560 McKINNEY RETRACTOR
spread 2"
blade width 15mm



RS-6561 COOK
non-magnetic
spread 1.5"
blade width 11mm
length 2"



RS-6570 CASTROVIEJO
non-magnetic
spread 35mm
blade length 15mm
blade depth 5mm
length 3³/₄"



RS-6585 DAVIS
3x3 blunt prongs
spread 2.5"
length 4¹/₂"



RS-6610

RS-6612

SENN
double end
length 6^{1/2}"
3 sharp prongs
3 blunt prongs



RS-6610 Shown

RS-6614

RAGNELL
double end
3mm x 5mm
5mm x 15mm
length 6"




RS-6628

Rake retractor
rigid shaft
length 6"
2 prongs, blunt



RS-6622 Shown

1-800-424-2984
www.roboz.com



RS-6630 Rake retractor
rigid shaft
length 6"
3 prongs, blunt



RS-6624 Shown

RS-6670 DESMARRES
length 5 1/2"
blade width 11mm
RS-6672 blade width 13mm




RS-6672 Shown

RS-8600 WEITLANER
2 x 3 prongs
spread 1 1/2"
length 4"
sharp
RS-8602 blunt



RS-8600 Shown





RS-8612 Shown

RS-8612

WEITLANER
3 x 4 prongs, blunt
spread 1^{3/4}"
length 5^{1/2}"

RS-8614

spread 3^{1/2}"
length 6^{1/2}"

RS-8616

spread 4^{3/4}"
length 8"

1-800-424-2984
www.roboz.com

